

Attachment of The Rollover

KeenCut Support - Flexi Models

Choose one end of the Rollover Flexi and place the brackets in both corners as shown in the picture.



The brackets are fixed with bolts through the predrilled holes of the aluminum frame, and then the bolts are fastened from underneath with the nuts.



After fixing both brackets, this is how it should look.



Place the support shelf in the correct position on top of the brackets and fix with the bolts/washers/nuts.



The support shelf is now correctly attached to the Rollover Flexi and a KeenCut EVO3 cutter can easily be fixed on top using the pre-drilled holes