

SureColor® V7000 Required Maintenance

There is no time for downtime when running your business.

Clean machines run better. When enough debris gets into the various components, wear can be accelerated, and output is negatively impacted. As the debris builds over time, it can impede the machine's performance and reduce reliability.

It is the customer's responsibility to conduct maintenance on time, as outlined below, to keep their printer up and running.

User Maintenance Schedule and Steps

Maintenance Frequency	Customer Steps
Daily	 Empty waste ink tank Clean media table Ensure print head nozzles and carriage are clean
Monthly	Clean UV lamps, ionizers, conveyors, chiller unit filter
As Needed	Top off UV cooling liquid

Please refer to product's Operator Maintenance and User's Guide for detailed maintenance requirements.

User maintenance is required. User maintenance is not included as part of the Extended Service Plans. Create a maintenance schedule, update maintenance records, and designate a regular maintenance employee to ensure your printer's productivity.

Customer Responsibilities

Customer is responsible for sourcing maintenance equipment, which includes the following approved parts:

- Cleaning cloth (Product code: C13S210050)
- Coolant (Part #C13S210135)

EPSON, SureColor are registered trademarks and the EPSON logo is a registered logomark of Seiko Epson Corporation. All product and brand names are trademarks and/or registered trademarks of their respective companies. Epson disclaims any and all rights in these marks. Copyright 2023 Epson America, Inc.